

PROTOCOL FOR CLEANING & DISINFECTING “PIPE-LESS” FOOT SPAS

*FOR UNITS WITH FOOTPLATES,
IMPELLERS, IMPELLER ASSEMBLIES AND PROPELLERS:*

After each client:

1. **Drain** water from the basin.
2. **Remove** impeller, footplate, and any other removable components according to the manufacturer's instructions.
3. Thoroughly **scrub** impeller, footplate, and/or other components and the areas behind each with a liquid soap and a clean, disinfected brush to remove all visible residue, then **reinsert** impeller, footplate, and/or other components.
4. **Rinse** the basin with clean water.
5. **Refill the basin** with clean water and **circulate *ACCEL* FOOT BATH CLEANER at 1:128 dilution (1 oz)** through the basin for **5 minutes**.
6. **Drain, rinse** and **wipe** dry with a clean **paper** towel.
7. **Disinfect** the tub with an EPA registered disinfectant according to manufacturers directions. Allow recommended contact time.
8. Rinse thoroughly.

At the end of every day:

1. **Clean** the screen and other removable parts and the area behind these with a brush and liquid soap & water to remove all visible residue and **replace** properly cleaned screen and other removable parts.
2. **Fill** the basin with water and add ***ACCEL* FOOT BATH CLEANER at 1:64 dilution (2 oz)**. **Circulate** through the spa system for **5 minutes**. If excessive foaming occurs, discontinue circulation and let soak for the remainder of the 5 minutes.
3. **Drain** the soapy solution and **rinse** the basin.
4. **Drain, rinse** and wipe dry with a clean **paper** towel.
5. Allow the basin to dry completely.
6. **Disinfect** the tub with an EPA registered disinfectant according to manufacturers directions. Leave for recommended contact time.
7. Rinse thoroughly.